





FOR MULTI OR PRE-WIRED METERS (MORE THAN 6) LINE FEED IS TO BE ATTACHED BEFORE MAIN SWITCH & SEALABLE WIRING TROUGH.

## URD SERVICE LATERAL AND METER